PANTONE® Formula Scale 3

Operating Manual

Models: PFS3-5-22, PFS3-5-12

PANTONE® is the property of Pantone, Inc. Copyright © Cherlyn Electronics Limited, 2006 Portions © Pantone, Inc., 2000

Introduction

The **PANTONE Formula Scale** is a microprocessor controlled digital weighing scale, specifically designed for fast, accurate mixing of printing inks to match defined colors, in particular the range of PANTONE Colors.

The scales are ready programmed with the formulas for mixing all of the colors found in the **PANTONE formula guide** *printer edition* (and PANTONE formula guide *designer edition*), the **PANTONE metallic guide 2006** (*coated*), and the **PANTONE pastel guide 2006** (*coated*).

The PANTONE Formula Scales can be used for mixing inks using any of the formulas stored in the scale. Once the required color has been selected, and quantity of ink required entered, the scale will compute the exact amounts of each of the base inks needed.

During the weighing sequence, the weight of each of the constituent bases required for the mix is shown as an amount to add. Also, to simplify and speed up operation, a progress bar monitors addition of the bases. By following the simple weighing sequence, an accurate formulation is assured.

The PANTONE Formula Scales are ruggedly constructed and will withstand the wear and tear of normal use. However, as with all precision weighing instruments, reasonable care should be exercised to ensure long and trouble free operation.

Preparation For Use

Unpacking and Assembly

Unpack the scale carefully, and retain the packing carton in case it should be needed again. Please read this Operating Manual carefully before attempting to use the scale.

Standard Scales – Models PFS3-5-xx

Locate the weigh pan centrally on the four rubber mounts protruding through the top of the scale case. It is important that there is no direct contact between the weighpan and the scale case.

Siting

For best results the scale should be placed on a firm, level surface, which is free from vibration, away from air currents and sources of heat. This is particularly important when using the high resolution weighing mode.

As with all precision weighing scales, best results are achieved after the scale has been switched on for a period of time. It is therefore good practice to leave the scale switched on between periods of use.

Electrical Connection

Check that the electrical supply meets the specifications shown at the rear of the scale before connecting to the supply.

IMPORTANT – THIS EQUIPMENT MUST BE EARTHED

USA & Canada – Model PFS3-5-12

Supply requirements are 120 Volts, 60 Hz, 0.25 Amps. Use the detachable power lead supplied. Should it ever become necessary to replace the plug, it must be wired according to the following convention:

Black	-	Live
White	-	Neutral
Green	-	Ground

FCC Notice This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Europe – Model PFS3-5-22

Supply requirements are 230 Volts, 50 Hz, 0.25 Amps. Use one of the detachable power leads supplied, either the UK (square pin) or European (round pin) type, as appropriate. The plug fitted to the UK lead must be fused at 3 Amps. Should it ever become necessary to replace the plug, it must be wired according to the following convention:

Brown	-	Live
Blue	-	Neutral
Green and Yellow	-	Earth

CE Notice The **C**€ mark on this equipment indicates that it complies with the Electrical Equipment (Safety) Regulations 1994 (S.I. 1994/3260) and Electromagnetic Compatibility Directives EN 50081-1 (Emissions) and EN 61000-6-2 (Immunity).

Applying Power

Switch on the scale using the power ON/OFF switch. The scale will go through an initial start-up sequence, during which information screens will be displayed. In particular, the Model Number and Firmware Version and scale Serial Number will be displayed for reference.

The scale will automatically set zero weight and display the color selection screen. It will then be ready to use.

Keyboard Operation

The keyboard is used to control the operation of the scale, and for inputting data. Keys are divided into three groups: Main Functions, Alphanumeric Keys, and 'Soft' Keys (where operation depends on the function selected and is software controlled).

Main Function Keys

There are eleven function keys, which control operation of the scale. These are color coded and identified by text indicating their use:

Selects the setup menu, used to determine how the scale will Menu operate. Pressing again returns to the previous function. Displays information about the current mix. Repeated pressing Info will step through available pages then return to the previous function. Selects the weighing function, which allows the scale to be used Weigh as a conventional digital weighing scale. Sets zero weight on the display. This key only operates in Set weighing mode and can be used to tare off the weight of a Zero container. Displays the color guides available so that one can be selected. Pantone Guide Enables a color to be selected from the currently selected color Pantone guide. Number For entering the quantity of ink required for the mix, using the Quantity numeric keypad. Start Starts the mixing sequence. This key may also be used to step on to the next ink during the mixing sequence. Mix

Numeric Keypad

The number keys are used to select colors from a range where they are identified by number, e.g. PANTONE Number.

Errors can be corrected by pressing the **[Esc]** key. Completed entries are confirmed by pressing **[Enter]**.

The **[Esc]** and **[Enter]** keys are also used in conjunction with the function keys when making selections. In general, pressing **[Enter]** will confirm a change, whereas pressing **[Esc]** will go back to the previous state.

Soft Keys

At the side of the display, there are three keys marked **[F1]** - **1** (up arrow), **[F2]** - ↓ (down arrow) and **[F3]** - **[SEL]** (select). The use of these keys changes under software control, depending on the scale function selected.

When menu lists are displayed, these keys are used to highlight and select items from menu lists. Use the 1 (up arrow) and 1 (down arrow) keys to highlight the required item and then press **[SEL]** to select.

The **[Esc]** and **[Enter]** keys are also used in conjunction with these keys. In general, pressing **[Enter]** will be the same as pressing **[SEL]** and will confirm a change, whereas pressing **[Esc]** will close the menu leaving the selection unchanged.

At other times, the **[F1]**, **[F2]** and **[F3]** keys may be assigned other functions, which will be described by the text on the screen adjacent to them.

PANTONE Color Ink Formulation

First, you must define the mix by selecting the color you require from one of the available color guides, then entering the quantity of ink needed. Next, step through the weighing sequence, adding the correct amount of each base ink as indicated. At the end of the mix, the accuracy of each component will be checked against pre-set accuracy levels, virtually eliminating the possibility of mistakes.

Color Guide

Press the **[PANTONE Guide]** function key to select the color guide that contains the color you require. You will be shown a list of all the color guides available for the ink system you are using. Use the 1 (up arrow) and 1 (down arrow) keys to move the highlight to select the one required.

Color Selection

Press the **[PANTONE Number]** function key to choose a color from the currently selected guide. The way the color is selected will depend on the available colors: -

Normally, PANTONE Colors can be selected by simply entering the 3 or 4 digit PANTONE Number.

The PANTONE formula guide contains some special groups of colors that are not referenced by a simple number, e.g. PANTONE Base Colors, PANTONE Warm Grays, etc. When special colors are available within a guide, the legend '**Special**' will appear alongside function key **[F1]**. Press this key to show a drop down list of available groups of colors; then use the **1** (up arrow) and **1** (down arrow) keys to highlight the one required and press **[SEL]** or **[Enter]** to select. This will show all the named colors in the selected group as a further drop down list. Use these keys again to select the color you require.

Quantity

Press the **[Quantity]** key to enter the amount of ink required for the mix, using the numerical keypad. Depending on the scale settings, this may be in kilograms, grams, or pounds.

Mixing Sequence

The mix parameters have now been defined, and the scale will automatically calculate the amounts of each of the base inks required, presented in the best order for weighing them out. Place a suitable container for the ink onto the weigh pan.

Start the mixing sequence by pressing the **[Start Mix]** key. The required quantities for the base inks are checked automatically to ensure that they can be weighed out accurately in standard weighing resolution. Normally, the screen will show the first base ink to add, the quantity required and the empty progress bar.

As the first base ink is added, the amount still required to add will reduce, and the progress bar will move along to provide a visual representation of how the addition is progressing. Continue to add the ink until the progress bar is full and the display shows zero.

Press the 'Next' function key [F1], or the [Start Mix] key to step on to the next base ink in the mix. Once again, add the ink until the display shows zero. Repeat for all of the components of the mix.

The progress of the mix can be checked at any time by pressing the **[Info]** key. Press the key repeatedly to step through the available pages of information and then return to the mixing sequence.

When all of the components have been added, press the **'End'** function key **[F2]**. The mix will be checked against the pre-set accuracy level, and a message will warn of any error, so that it can be corrected.

Correcting Mixing Errors

Sometimes too much of one or more base inks may be added in error. The display will change from '**Add**' to '**Remove**' and show the excess quantity. For the first component the excess can easily be removed, but this may not be possible for subsequent base inks.

Should this problem occur, the scale is able to recalculate the mix quantity required to just use up the excess. Press the **[Recalc]** key, or function key **[F3]**, which will be active whenever too much of any of the bases has been added. You can then confirm the new quantity and continue with the mixing sequence.

Other Features

Weighing

Press the **[Weigh]** key to use the PANTONE Formula Scale as a conventional digital electronic weighing scale in standard resolution. The scales are suitable for weighing up to 6 kg /12 lb with standard resolution of 1 gram / 0.001 lb.

Depending on the option selected using the Setup Menu, the scale will display weight either in kilograms, grams or pounds.

The **[Set Zero]** key may be pressed to reset zero weight, or to tare off any weight on the weighpan. Note that this key only functions when weight is being displayed.

Setup Menu

The scale provides the user with a number of options, which can be changed to suit particular requirements. Press the **[Menu]** key to access the Setup Menu. Use the **1** (up arrow) and **4** (down arrow) keys to highlight the item you wish to change, then press **[SEL]** or **[Enter]** to select. Use these keys again to select the option you require.

When you have finished, you can exit the Setup Menu by pressing any of the main function keys. The new settings will be remembered, even when the scale is turned off.

Contrast This allows you to adjust the display contrast for optimum viewing conditions.

Backlight The scales have a built-in display backlight, which will make the display easier to read under most viewing conditions. This may be turned off if preferred.

Weighing Units This option determines whether weight will be displayed in kilograms, grams or pounds.

Beep Operation of the keys may be confirmed by a short audible tone. This may be turned off if preferred.

Accuracy Checking This option selects the level of the accuracy check which is applied at the end of each mix. Maximum accuracy requires that all components of the mix be reduced to zero.

Language This option selects the language to be used for all of the on-screen messages.

Context Sensitive Information

From any of the main function screens, pressing the **[Info]** key will display context sensitive information.

Repeat pressing of the key will step through the available information pages if there is more than one, and then return to the original function.

Warning Messages

The PANTONE Formula Scale is continuously monitoring its operation to ensure that an accurate ink formulation is achieved. Below is a list of some of the more common warning messages, together with suggested remedies:

Number not found Either an error has been made entering a number, or the number does not exist in the selected color guide. Press **[Esc]**, then reenter the correct number or change to the correct color guide.

Invalid Quantity The mix quantity entered is either zero or outside the mixing capacity of the scale. Press **[Esc]**, then enter a new quantity.

Container Too Heavy You have attempted to start a mix for which the combined weight of the container on the weighpan and the ink mix will exceed the weighing capacity of the scale. Use a lighter container or reduce the mix quantity.

Quantity Too Small You have attempted to start a mix in which one or more of the component bases is too small to weigh accurately in the weighing resolution selected. Press **[Esc]**, then **[Info]** to examine the mix and see the problem. If there is still a problem, increase the mix quantity so that the smallest component is at least 5 scale divisions.

Mix Outside Accuracy Limits At the end of a mix, one or more of the bases added is outside the pre-set accuracy level. Press **[Enter]** then resume the mix to correct the problem.

Recalculation Failed You have added too much of a component to a mix, and attempted to recalculate a new quantity to use it up. The recalculated quantity of ink will result in the finished mix exceeding the weighing capacity of the scale. To continue, you must remove some of the excess component.

Too Much Ink Added You are in the middle of a mix and have added too much of one of the components, so that the combined weight of the container on the weighpan and the rest of the ink mix will exceed the weighing capacity of the scale. Press **[Esc]** to go back and remove the excess.

Maintenance

The scale has no moving parts and requires no routine maintenance. In the unlikely event of a fault developing, switch the scale off and disconnect from the mains power supply. Contact your supplier with details of the problems.

Repairs to the scale must only be carried out by an authorised service engineer.

Cleaning

Any accidental spillage of ink onto the scale should be wiped up immediately with a dry cloth. If further cleaning is necessary, first disconnect from the mains supply, then wipe with a soft cloth that has been lightly moistened with a suitable solvent.

WARNING: Many solvents and proprietary press cleaners are very aggressive and should only be used with great caution. These may permanently damage the keyboard and case, especially with repeated application. If in doubt, test the cleaner you intend to use on a small area. Do not use if there is any sign of solvent attack on the case or keyboard materials.

Specifications

Cherlyn Electronics Limited Brookmount Court, Kings Hedges Road, Cambridge CB4 2QH, England. 08/06